

# Teenage Engineering OP-1 Default patches

The OP-1 comes preset with these patches:

	engine / patch
S button	1. Digital / Signal
	2. Cluster / Wood Xylo
	3. Dr Wave / Bic Base
	4. FM / Wonky Organ
	5. Phase / Pure
	6. Pulse / Burger
	7. String / Honki Tonk
	8. Sampler / Piano Lo

Engines:

Cluster  
Digital  
Dr Wave  
FM  
Phase  
Pulse  
Sampler  
String

DNA, Dsynth and Snapshot can also be accessed via the Engine list.

Cluster:	Air Base	Digital:	64	Dr Wave:	Bic Base
	Air Raid		Clavi		Bit Talk
	Blow		Coin		Echoes
	Clash Beep		Cosmic Phone		Frogger
	Close Bass		Creepy Violin		Jaw Base
	Lead Star		Dump		Monster
	Light Pop		G-Wind		Munnen
	Mosquitos		Noise Brick		Plux
	Popping		Oboe		Resclav
	Smooth		Octaves		Robot
	Sub		Okarina		Simple
	Throb		Pad		Sweep
	Unitor		Phaser		Talk Box
	Whistle		Signal		Toy Piano
	Windy Night		Stylus		Triangle
	Wood Xylo		Wobble		

Access the following patches by pressing  
SHIFT + S1-S8  
then use blue and green encoders (knobs) to select  
engine (blue knob) and patch (green knob)

To change just the engine you can press  
SHIFT + T1-T4

FM:	Bell	Phase:	Angry Flute	Sampler:	Chord	String:	Critics Pick
	Chords		Bass		Clavi Harp		Damper Don
	Click Bass		Drops		Clavinet		Hacked Piano
	Dice		Enigma Pad		Game		Honki Tonk
	Dist Bass		Face		Hanabi		Koto JP
	Drops		Fleas		Music Box		Owowow
	FMBass		Flute		Organ		Pad
	Game		Funny Vib		Piano Hi		Pan Elektro
	Gear Down		Gurgle		Piano Lo		Power Bow
	Ice		Laser Beam		Pow		Rattle
	Lightbike		Odd P and K		Rhodes		Real Bass
	Organ		Pure		Rub		Slap Bass
	Plexi-Bass		Repeat		Sine Sub		Slide
	Popping		Scarry Lead		Slap		Strings Lead
	Soft Bass		Sharf		Space Lead		Swingin Mics
	Wonky Organ		Sub Bass		Thud		Tights
			Whee				